

No.	Description	Code	Qty
1	M10 Hex. Nut	40-31	8
2	M10 Lock Washer	40-32	8
3	Main Head	32-01	1
4	4 x 36 Drive Pin	26-02	1
5	Pin (31)	26-03	2
6	CE-12.7 Snap Ring	26-04	4
7	Latch	26-05	1
8	Spring Holder	26-06	1
9	Spring (81)	26-07	1
10	Head Shear	32-02	1
11	Stud Bolt (2)	26-09	4
12	Spacer	32-03	1
13	M5 X 10 Screw (D.P)	55A-11	1
14	Body Head	32-05	1
15	Blade	32-06	1
16	Spring (375)	32-07	1
17	Ram	32-08	1
18	Blade Screw	32-09	1
19	P-45 Back Up Ring (B.C)	32-10	1
20	P-45 O-Ring	32-11	1
21	Exhaust Valve Screw	26-19	1
22	Copper Gasket (4)	26-20	1
23	Spring (68)	26-21	1
24	1/4" Ball	26-22	1
25	Spring (4)	16-48	1
26	3/16" Ball	16-49	2
27	M6 x 15 Screw (F.P.I)	32-23	1
28	2.5 x 20 Drive Pin	32-13	1
29	Release Knob Label	32-14	1
30	Release Knob	32-15	1
31	Release Valve Stem	32-16	1
32	P-3 O-Ring	16-36	1
33	7/32" Ball	16-26	1
34	Spring (76)	16-39	1
35	9/32" Ball	16-40	1
36	M10 x 10 Srew (F.P.)	16-41	1
37	PS-9 Pent Seal	32-18	1

Model P-100 Parts List

