




44	Pump Handle	16-31	1
45	Pump Handle Grip	16-32	1
46	PS-8 Pent Seal	16-44	2
47	P-8 Back-Up Ring (E.L.)	16-45	1
48	Gland	16-46	1
49	Pump Piston	16-47	1
50	Spring (4)	16-48	1
51	3/16" Ball	16-49	1
52	Copper Gasket (6)	16-50	1
53	Suction Valve Screw Ass'y	16-51	1
54	P-26 O-Ring	16-55	1
55	Oil Reservoir	40A-07	1
56	Reservoir Cap	410-55	1
57	M4 x 5 Screw (C.P)	55A-24	1
58	Body Handle	75-31	1
59	Grip Base	40-56	1
60	Body Handle Grip	40-57	1
61	5 x 14 Drive Pin	75-32	2
62	2 x 12 Drive Pin	40-21	1